

# Using the Power Outage Alert System:

Once the Power Outage Alert System is programmed you will need to test it. This is done while testing the UPS.

## Testing the System:

Disconnect the input power to the Power System. This will trigger the Alarm to alert you and call the numbers that it is programmed to call. Once you receive a call informing you the zone "is not OK" and the "utility power is out". The system will continue to call you until either the alarm is acknowledged or the alarm is back to normal.

Reconnect the utility power. On doing this you will not receive another phone call but the system speaker will announce that the zone "is now OK".

## The 3 Important things you need to know while using the alarm system:

### 1) Acknowledging the Alarm

Once the power is out the system will start to call all the numbers that it has been programmed for – until someone acknowledges the alarm. You acknowledge the alarm by pressing 555.

### 2) Getting a Status Report Remotely:

You can get a status report remotely by calling the alarm:

- a) Dial the telephone number of the Model 400.
- b) Let the telephone ring once and then hang up.
- c) Wait approximately ten seconds
- d) Call the Model 400 back.

It will answer the telephone on the first ring.

The System will provide a current Status Report.

### 3) Understanding the Alert Calls:

The system will make 2 outgoing calls:

- a) Call to inform that the input (utility power) is out.
- b) Call to inform the refrigerator (output power) is out and batteries are dead.

